







MESH Wireless

Design Francisco Gomez Paz, 2018

**LUCE
PLAN**

- Type: Suspension
- Light source: **D86KW080** LED 50W 2700K
D86KW100 LED 61W 2700K
- Minimum App requirement:  
- Network requirement:  WiFi 2,4 GHz
- Product use: Indoor
- Materials: Structure in steel, lenses in polycarbonate
- Colors: Black
- Description: Thanks to a wireless kit available for the Mesh suspensions large (Ø 100) and medium (Ø 80), users can interact with the lamp by means of a smart device. Luceplan has developed a special app (for iOS and Android) that makes it possible to control single or multiple units, individually or as a group.



Insulation class and mark:   

Rating: 220-240 V ~ 50/60 Hz, 50W D86KW080
220-240 V ~ 50/60 Hz, 61W D86KW100

Reference code: Structure


Mesh complete, kit wireless included, Ø 80 cm

D86KW081A	1D86KW081001A	cable lenght 1 m
D86KW082A	1D86KW082001A	cable lenght 2 m
D86KW083A	1D86KW083001A	cable lenght 3 m
D86KW084A	1D86KW084001A	cable lenght 4 m
D86KW085A	1D86KW085001A	cable lenght 5 m

Mesh complete, kit wireless included, Ø 100 cm


D86KW101A	1D86KW101001A	cable lenght 1 m
D86KW102A	1D86KW102001A	cable lenght 2 m
D86KW103A	1D86KW103001A	cable lenght 3 m
D86KW104A	1D86KW104001A	cable lenght 4 m
D86KW105A	1D86KW105001A	cable lenght 5 m

D86KW80






Ceiling rose: Ø 30 x 7 cm

D86KW100




Ceiling rose: Ø 30 x 7 cm




Luceplan Mesh




Google Play
App Store

NEW

Don't use characters: . , " ° £ /

APP:  www.luceplan.com/products/mesh-wireless

Mesh master PSK  luceplan

Light scenarios





MESH Wireless

Design Francisco Gomez Paz




HOW IT WORKS

Mesh is controlled by a dedicated electronic board which is located in the ceiling rose. The board needs to be connected to a normally open push button in order to dim the light or to control the different scenes, and to an on/off switch.



Press the switch to turn on the lamp




Press and hold to dim the lamp

HOW IT WORKS (choose the scenario)

PRESET SCENARIO


1. COMPLETE

2. LOWER ZONE




x2


Press the button twice to select scenarios



x2




x2




x2

5. YOUR SCENARIO

4. YOUR SCENARIO



x2



MESH Wireless

Design Francisco Gomez Paz

HOW TO INSTALL Mesh wireless controlled by wall buttons.
(This does not require uninstalling the Mesh App)

